




INSTALLATION INSTRUCTIONS 3AN VACUUM PORT ADAPTER

Document: 19-0192
Support: info@radiumauto.com

This product is compatible with the following Radium Engineering products:

- Multi-Pump Regulator** (20-0100-XX)
- Direct Mount Regulator** (20-0223-XX, 20-0393-XX, 20-0418-XX)
- FST-R Surge Tank** (Part number varies)
- FPD-XR Fuel Pulse Damper** (20-0177, 20-0179, 20-0200-XX)

STEP	TOOLS NEEDED	INSTRUCTIONS	PHOTO
1	Pliers	Use pliers to grab and unscrew the hose barb vacuum nipple installed in the product.	
2	Thread locker	Apply a small amount of red thread locking product to the small threads of the adapter fitting. Radium recommends Loctite 268. Make sure no thread locker gets into the internal passageway of the fitting.	
3	5/16" Wrench	Screw in the adapter and tighten to approximately 50 in-lb (6 N-M).	
NOTE		When connecting or disconnecting a 3AN hose, hold the adapter with a 5/16" wrench while tightening/loosening the hose-end.	