

# FORD FOCUS ST CATCH CAN STAGE 2

## TOOLS REQUIRED

M6 allen wrench  
Flat screw driver

## MATERIALS REQUIRED

<p><b>1</b></p> <p>Remove the engine cover.</p>	<p><b>2</b></p> <p>Disconnect the MAP sensor and remove the bolts holding the intake manifold. Pull the manifold away from the engine.</p>	<p><b>3</b></p> <p>Remove the clip holding the knock sensor. Disconnect the vent line from the intake manifold.</p>	<p><b>4</b></p> <p>Score the vent hose and remove it from the fitting connected to the engine block.</p>
			
<p><b>5</b></p> <p>Remove vent hose from the fitting.</p>	<p><b>6</b></p> <p>Oil the inside of the supplied vent lines.</p>	<p><b>7</b></p> <p>Install the shorter line onto the fitting and secure it with the hose clamp.</p>	<p><b>8</b></p> <p>Connect the vent line to the engine block connector and secure it with the hose clamp.</p>
			
<p><b>9</b></p> <p>Connect the vent line to the intake manifold.</p>	<p><b>10</b></p> <p>Make sure that the wire harness is routed under the intake manifold.</p>	<p><b>11</b></p> <p>Reinstall the intake manifold. Connect the MAP sensor.</p>	<p><b>12</b></p> <p>Install the Catch Can bracket.</p>
			

13

Install the Catch Can. Connect the vent lines.



14

Install the engine cover.

