

FORD FOCUS ST BRAKE DUCTS

TOOLS REQUIRED

M10, M18 sockets
M5 allen wrench

MATERIALS REQUIRED

None

<p>1 When lifting the car always use stands to secure the car.</p>	<p>2 Remove the right front wheel.</p>	<p>3 Remove the brake caliper.</p>	<p>4 Remove the brake rotor.</p>
			
<p>5 Remove the screws securing dust shield.</p>	<p>6 Remove the dust shield.</p>	<p>7 Reinstall the brake rotor.</p>	<p>8 Reinstall the brake caliper.</p>
			
<p>9 Prepare the Boomba Racing brake ducts.</p>	<p>10 Install the right brake duct and secure it to the lower arm.</p>	<p>11 Trim the splash guard in front of the brake duct to allow better air flow.</p>	<p>12 Follow steps 1 to 11 to install the driver side brake duct.</p>
			