

SUBARU WRX '15+

CATCH CAN STAGE 2

TOOLS REQUIRED

M12 sockets
M4, M6 allen wrench
Flat screw driver
Pliers

MATERIALS REQUIRED

<p>1</p> <p>Remove the engine cover.</p>	<p>2</p> <p>Remove the intercooler bolt and loosen the intercooler inlet hose clamp.</p>	<p>3</p> <p>Remove the intercooler bolts and loosen the intercooler outlet hose clamp.</p>	<p>4</p> <p>Remove the intercooler. Catch can connection is located under the intake manifold.</p>
			
<p>5</p> <p>Remove the factory vent line.</p>	<p>6</p> <p>Cut the factory vent line.</p>	<p>7</p> <p>Prepare the Boomba Racing Catch Can for installation.</p>	<p>8</p> <p>Prepare the outlet vacuum line. Connect supplied (18" long) vacuum line to the cut portion of the factory vacuum line. Secure with hose clamps.</p>
			
<p>9</p> <p>Connect the vacuum lines to the engine block and to the intake manifold.</p>	<p>10</p> <p>Install the intercooler. Secure inlet and outlet with the hose clamps.</p>	<p>11</p> <p>Install the catch can mounting bracket.</p>	<p>12</p> <p>Install the Boomba Racing Catch Can. Tighten the catch can clamp.</p>
			

13

Connect the vent lines. "OUT" line should be connected to the intake manifold. "IN" line should be connected to the engine block.



14

Install the engine cover.

