

# WeatherTech®



## Cargo Liners

- Complete trunk and cargo area protection
- Digitally designed for each application
- Remains flexible under temperature extremes
- Available for car trunks, SUVs and minivans

## Fitting Instructions

Your new WeatherTech® Cargo Liner is custom molded to fit your particular vehicle. Upon removal from the box, you will notice that the liner may not completely unroll and lie flat. This is normal and only temporary. Just place the liner on the floor, or in the back of your vehicle with a weight on each corner (books work well). After about 15 minutes, your liner will remain flat.

Your liner is made from an engineered resin that is both lightweight and extremely durable. The easiest way to clean your liner is with a damp cloth or sponge. For the best results use WeatherTech® TechCare® FloorLiner™ & FloorMat Cleaner and Protector. We do not recommend Armor-All® or STP Son-of-a-Gun® as these types of products make the liner slick, and cargo will slide.