

# CIVIC X - CATCH CAN STAGE 1

## TOOLS REQUIRED

M12 socket wrench  
4 MM allen wrench  
5 MM allen wrench  
Flat screw driver  
Pliers

## MATERIALS REQUIRED

Mobil 1 synthetic grease

|  |   |  |   |
|--|---|--|---|
| <p><b>1</b></p>  | <p>Secure the universal mounting bracket to the Catch Can.</p>                      | <p><b>2</b></p>  | <p>Prepare the installation kit.</p>  |
|    |    |    |                                      |
| <p><b>5</b></p>  | <p>Secure catch can to the bracket.</p>   | <p><b>6</b></p>  | <p>Remove the vent hose.</p>  |
|  |  | <p><b>7</b></p>  | <p>Grease the vent adaptors.</p>  |
| <p><b>9</b></p>  | <p>Turn the fitting so the hose adaptor side is in "10 O'clock location.</p>        | <p><b>10</b></p>   | <p>Push the hose fitting on the intake's vent nipple. Wiggle it and turn during installation. Push all the way in.</p>  |
|  |  | <p><b>11</b></p>   | <p>Secure catch can to the bracket. Connect the valve cover to the "IN" port. Connect the intake to the "OUT" port.</p> |
|  |  |  | <p><b>12</b></p>  |
|  |   |  | <p>Dress up the vent lines with the zip ties.</p>   |
|  |   |  |                                    |