

# VELOSTER TURBO 19+ CATCH CAN STAGE 2

## TOOLS REQUIRED

Pliers  
M10 socket wrench  
4 mm Allen wrench  
Flat screw driver

Razor blade

## MATERIALS REQUIRED

None

<p><b>1</b></p> <p>Prepare Veloster 19+ Stage 2 mounting kit.</p>	<p><b>2</b></p> <p>Secure the mounting bracket to the Catch Can</p>	<p><b>3</b></p> <p>Connect the vent hoses to the Catch Can and secure them with the included clamps.</p>	<p><b>4</b></p> <p>Install the hose fittings the vent hoses and secure them with the included clamps.</p>
			
<p><b>5</b></p> <p>Remove the engine cover.</p>	<p><b>6</b></p> <p>Mount the Catch Can beside the front driver side headlight using the existing bolts.</p>	<p><b>7</b></p> <p>Remove the foam insulation from the factory vent line.</p>	<p><b>8</b></p> <p>Cut the factory vent line approximately 5.5" (140 mm) from the top end.</p>
			
<p><b>9</b></p> <p>Connect the vent hoses. Connect the vent line from the valve cover to the "IN" port. Connect the vent line from the intake manifold to the "OUT" port.</p>	<p><b>10</b></p> <p>Use the zip ties to dress up the vent hoses.</p>	<p><b>11</b></p> <p>Install the engine cover.</p>	
			