

B8 A4 Exhaust Install




604.530.3092
www.ctsturbo.com
#309-20630 Mufford Cre. Langley

Step 1 - Remove two front and two rear catback hangers



Step 2 - Loosen the clamp from the down pipe and remove factory catback



Note: - If switching to dual mufflers install new valance

Step 3 - Hang the front section of the catback on the car



Step 4 - Install y pipe and passenger pipe

Note: Leave the clamps loose for adjustment




Step 5 - Transfer Hanger to the new muffler



Step 6 - Slip the driver side muffler onto y pipe and attach hanger



Step 7 - Do the same for the passenger side



Step 8 - Install the tips



Step 9 - Adjust exhaust and tighten clamps

