



INSTALLATION GUIDE
CTS-HW-310



20630 Mufford Crescent, Unit #309
Langley, British Columbia V2Y 2V9
www.CTSTURBO.com

WHAT IS INCLUDED

1x Right side paddle extension

1x Left side paddle extension

Retaining clips and set screws are pre-installed. Do not lose these when unpackaging your extensions

**TOOLS Required**

1.5mm Allen Key

NOTES

Vehicle in this installation guide is a 2016 VW Golf R

STEP 1

Locate factory paddle shifter. These typically are located on the back of the steering wheel to the left and right side. Manual transmission cars do not have these.



STEP 2

Place CTS Paddle shifter extension onto paddle. Taking care not to lose the retaining clip that is pre-installed into the extension.



STEP 3

Carefully tighten the 1.5mm allen bolt to secure the extension onto the paddle. Do not over tighten. These just need to be snug.



STEP 4

Repeat for other side and enjoy.

