

PERRIN

2022+ WRX License Plate Delete

2022-09-14

PSP-BDY-116

Thank you for purchasing this PERRIN product for your car! Installation of this product should only be performed by persons experienced with installation of aftermarket performance parts and proper operation of high performance vehicles. If vehicle needs to be raised off the ground for installation, the installer must use proper jacks, jack-stands and/or a professional vehicle hoist for safety of the installer and to protect property. If the vehicle is lifted improperly, serious injury or death may occur! Please read through all instructions before performing any portion of installation. If you have any questions, please contact our tech department prior to starting installation. We can be reached in any of the following methods:

Email Tech@PERRIN.com

Instant Chat off the main page of www.PERRIN.com

Or simply call our tech team at 503-693-1702



WARNING: This product can expose you to chemicals including Lead which is known to the State of California to cause cancer birth defects or other reproductive harm. For more information, go to www.P65Warnings.ca.gov

SPECIAL NOTES:

- In some states it is not legal to remove front plate from car. Please check with local law enforcement before installing.
- Plate delete can be mounted either direction with bold PERRIN facing out or Outlined PERRIN facing out.

Parts Included with the PERRIN License Plate Delete:

- (1) PERRIN License Plate Delete for 2022 WRX
- (2) #14 x3/4" Phillips Truss Head SS Screw Black Oxide
- (2) M6 x 14mm Button Head Socket cap screw Black Oxide SS

Installation of PERRIN License Plate Delete

1. If no license plate has been installed or the OEM bracket was NOT used:
 - a. Locate (2) small dimples in bumper where screws will be installed to.
 - b. Carefully install supplied sheet metal screws into bumper through the dimples.
 - c. Remove screws from bumper, then mount PERRIN Plate Delete using the same sheet metal screws.



2. If license plate is installed with OEM bracket:
 - a. Remove license plate from bracket.
 - b. Remove (2) M6 bolts holding OEM bracket to bumper and remove bracket from bumper.
 - c. Take note of rubber well nuts left behind in bumper. Take care to NOT push these into the bumper as they will need to be recovered in order to install PERRIN Plate Delete.
 - d. Mount PERRIN Plate Delete to bumper using supplied M6 screws.
3. After a few days of driving, check that screws are still tight to ensure plate doesn't fall off car.

Questions, Comments, and Suggestions Contact: Tech@PERRIN.com

Visit Our Website for Instant Chat Options at www.PERRIN.com

Call Our Tech Team at 503-693-1702